



Bed Tie-Down Anchors - Installation Guide

Application: Tundra, Tacoma, F-250, F-350

1. Remove factory anchors using a T40 Torx bit. If you have a spray-in bedliner, first cut along the edge of the anchor using a razor blade. Use a pick or small screwdriver to remove the bedliner inside the Torx head. Lightly tap the T40 bit into the screw head and remove. Charvonia Design Tie-Down Anchors are wider than the factory anchors and will usually cover any missing bedliner.
2. Install the Charvonia Design Tie-Down Anchors using the provided bolts and a 6mm hex bit. Use Anti-seize or similar and torque to 20 ft/lbs.

Helpful Tips:

Never exceed the load capacity of your vehicle.

Use multiple straps to share the load and provide redundancy.

Check bolt tightness before attaching straps to Tie-Down Anchors.