

## Rail Tie-Down Anchors - Installation Guide

## Toyota Tundra & Tacoma

- 1. Remove plastic end caps from rails.
- 2. Loosely assemble Tie-Down Anchor to threaded plate using provided bolts. Position threaded plate with step facing the Tie-Down Anchor.
- 3. Slide assembly into end of rail. Align step on threaded plate with notch inside rail.
- 4. Tighten bolts using 6mm hex wrench and reinstall end caps.

## Jeep Gladiator

- 1. Drop threaded plate into rail slot with step facing you. Align step on threaded plate with notch inside rail.
- 2. Assemble Tie-Down Anchor to threaded plate using provided bolts.
- 3. Tighten bolts using 6mm hex wrench.

**Helpful Tips:** If you can't slide the Tie-Down Anchor in from the end of the rail, remove the rail using a Torx bit.

Never exceed the load capacity of your vehicle.

Use multiple straps to share the load and provide redundancy.

Check bolt tightness before attaching straps to Tie-Down Anchors.

Part Number: RTD-05 Patent Pending info@billettiedowns.com